LEVOLOR InMotion:
Amazon Alexa Quick Start Guide

Getting Started


In order to take advantage of Alexa voice commands with LEVOLOR InMotion, you need:


- LEVOLOR InMotion account and hub
- Alexa app downloaded on your mobile device


Enable Alexa Skill

1 Open the Alexa app on your mobile device. Select “More” in the bottom right corner then “Skills & Games”.


2 Select the magnifying glass in the top right corner then search “LEVOLOR InMotion”.









3 Select the LEVOLOR InMotion Skill and tap “Enable to Use”. Sign into your LEVOLOR InMotion account to link with Alexa.





LEVOLOR InMotion:
Amazon Alexa Quick Start Guide

4 After confirmation, select “Discover Devices”.



5 Begin activating your InMotion shades using Amazon Alexa voice commands. See a chart of basic commands on the next page.

Additional Tips:

- Before attempting to discover your shades in the Alexa app, please ensure your hub is registered to your InMotion account.
- After your shades have been discovered in the Alexa app, use the “Add Group” feature in the Devices tab to combine them with other smart devices in your home for integrated voice-activated control.
- If you did not discover all of your shades after linking to your account, or you need to discover new devices in the future, you can add them later by selecting “Add Device” in the main menu.

LEVOLOR InMotion:
Amazon Alexa Quick Start Guide

Voice Commands

Activate your LEVOLOR InMotion blinds and shades using Amazon Alexa voice commands. Use the shade names assigned in the LEVOLOR InMotion app when using voice commands.

Command	Creating the Function
"Alexa, open/close (shade name)"	To control an individual shade, start with "open" and "close" then the shade name. Do not add the "blind", "blinds", "shade" or "shades" at the end.
"Alexa, open/close/set (shade name) to 35% position"	To move an individual shade to a specific % position, start with "open", "close", or "set" then the shade name and the phrase "to % position".
"Alexa, raise/lower (shade name)"	To move an individual shade to a 5% difference of current position, start with "raise" or "lower" then the shade name. e.g. The current shade's position is 35%. After this voice command, the shade will go to 30% if you say "raise" or 40% if you say "lower".
"Alexa, open/close (Alexa group name)"	To group control shades: Please be aware that the rooms you have setup in the InMotion app will not automatically show up in your Alexa app. It is required to recreate and group the shades in your Alexa app. Once the group has been created in the Alexa app, start with "open" or "close" then the group name. Do not add the word "blind", "blinds", "shade" or "shades". e.g. You recreate a group named "Office" in the Alexa app with multiple shades. Say "Alexa, open Office." to operate.
"Alexa, turn on (InMotion scene name)"	To activate an InMotion scene, start with "turn on" followed by the scene name.

© LEVOLOR® 2022
20-0048-202